


RHINO-RACK®

Mitsubishi Triton Gen6 and Nissan Navara Gen4, Double Cab Backbone RMTB2

Important:

1. Check the Rhino-Rack website to ensure you have the latest issue of these instructions.
2. Please refer to your fitting instruction to ensure that the roof racks are installed in the correct locations.
3. Check the contents of kit before commencing fitment and report any discrepancies.
4. These instructions must be followed for warranty to be upheld.

Fit Time: 30 mins




RHINORACK.COM

Doc. No: 520-RFI-00290

Issue No: 01

Issue Date: 19/03/2026



Distribute loads evenly and laterally/longitudinally as low as possible over the span.

Avoid point loads concentrated at the front or rear.

Without a load:




Do not exceed a maximum speed of
130 km/h (80 mph)



130 KM/H

80 MPH



With a load:




Do not exceed a maximum speed of
100 km/h (62MPH)




100 KM/H



62 MPH





Use extreme caution transporting wind-resistant loads when cornering or braking.



Off-road conditions can be more rigorous. Use extreme caution on paths without a sealed surface like tar or bitumen.






Long flexible loads must **attach securely to rigid support** and be tied down to the bonnet




Surfboard Overhang > **600mm** must be tied to the bonnet






Loads must be tied down to Cross Bars, not around backbone



Use only non-stretch fastening ropes or straps to attach cargo to roof racks




Ensure sunroof will not collide with roof rack system.



If tying down open awnings, attach any tension strap or guy ropes to the platform or an anchor on the platform.

DO NOT tie off to the backbone blades.







Racks must be removed when vehicle is put through an automatic car wash.




Ensure Ladder is well supported on the ground to support tent. Take extreme caution when climbing heights above 1.2m/4ft.

Tub/tray/canopys can move independently from the vehicle cabin. Rigidly fix to either the cabin roof racks **or** the tub/tray/canopy roof racks but not both simultaneously.




[Youtube.com/Rhinorackaustralia](https://www.youtube.com/Rhinorackaustralia)

Check the website and the vehicle owners hand book for your vehicle manufacturer's maximum carrying capacity. Load must be evenly distributed over the system.



Cargo Load Limit

Total permissible weight allowed on top, and attached to the rack whilst the vehicle is in motion.



System Weight

Total weight of the rack system. (e.g. Crossbars, Backbone, Platform)



Max System Load Capacity

Please ensure you use the vehicle manufacturer's maximum roof allowance if it is lower than the figure listed in the fitting chart/supplement.



Vehicle Manufacturer's Load Limit

Total permissible weight attached to the rack. This is inclusive of the weight of the rack system.

- Check part number or kit is correct for use with your vehicle.
- Do not attempt to fit the rack system to your vehicle unless you fully understand these fitting instructions. Please direct any questions regarding fitting to the dealer from where the roof racks were purchased.
- Off-road conditions can be much more rigorous. Extreme care must be taken on any driven path that does not contain a surface protection layer (tar/bitumen).
- Racks must be removed when vehicle is put through an automatic car wash.
- With utility/pick up vehicles, the cabin and the utility tray/truck bed move independently. Racks and vehicle can be damaged if the item transported is rigidly fixed at points on both the cabin and utility tray/truck bed. Instead, rigidly fix to either the utility tray/bed racks or the canopy roof racks.
- Always ensure you fasten your load securely.
- Use only non-stretch fastening ropes or straps to attach cargo to your load.

In Service Maintenance Checks

- All bolt connections should be checked after driving a short distance when you first install your roof racks.
- All bolted connections should be checked again at regular intervals (weekly is recommended, depending on road conditions, usage, loads and distances travelled).
- All bolted connections should be checked each time they are re-fitted.
- Off-road conditions are more rigorous. Check all bolted connections and your load more regularly.
- Ensure that your vehicle manufacturer's GVM, and gross axle weights are not exceeded (refer to vehicle owner's manual).

Torque Settings:

Unless stated otherwise in these instructions, all fasteners should be set to the following torque settings:



Note for Dealers and Fitters

It is your responsibility to ensure these fitting instructions are given to the end user or client. These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.

Warranty





We love creating our products for you and hope you love using them too.

For complete peace of mind, register your product at www.rhinorack.com/warranty.

This way, we can quickly help you with any future approved fitment warranty claims.

And remember – never to forget to **Make Space For Adventure!**

Parts list

Right Backbone  A x1	Left Backbone  B x1	M8 T Bolt  C x6	M8 Nyloc Nut  D x6
Instruction  E x1			

TOOLS REQUIRED:

T1 - 10mm Spanner / Torque Wrench

T2 - 13mm Spanner / Torque Wrench


NOTE

Complete installation of the RCP94-BK kit to the vehicle, before commencing these instructions.


Four M6x25 Hex Head Flanged bolts from the RCP94-BK are required to complete the installation of this backbone.

M6 x 25 Hex Head Flanged Bolts  x4
--


- 1** Identify the location of the 4 pre-assembled RCP94-BK bases.



- 2** Loosely assemble **A** and **B** to the bases with the four M6x25 Hex Head Flanged bolts supplied in the RCP94-BK kit.




- 3**



PIONEER PLATFORM INSTALLATION *Refer to Pioneer Instructions*

4




rhinorack.com/roof

1. Complete **Fit my vehicle** journey
2. Select your **Product Solution**
3. Scroll down to '**Product Details**'
4. Select the '**INSTRUCTIONS**' tab to View the Fitting Chart
5. Space your Underbars to the dimensions provided.




VIEW FIT CHART


5



- 6** Ensure the Pioneer is facing the correct direction.



7



8

